

Easterly

User Guide





Inspired by adventures. Unbound.

Safety & Disclaimer

Important:

Before using your Pull-About, please read the user guide carefully. For questions and additional information, please visit our website at **easterly.au**

Safety & Disclaimer:

Please note that all safety and disclaimer information is subject to potential updates, which will be made solely at the discretion of Easterly. For the latest and most current information, visit our website at **easterly.au**



Warning:

Using this product without due care and responsibility could lead to injuries or even potential harm to yourself and others. It's important to exercise caution and apply common sense when using this product. Ensure adult supervision when in use.

Always read and follow all warnings and instructions for the Pull-About and any accessory product you purchase for use with it.

- Be careful when using on an incline.
- When stationary, position Pull Handle upright to avoid becoming a trip hazard.
- Do not over-inflate your rear tyres. Failure to comply with the rated tyre sidewall pressure (36 PSI) may lead to explosion of the tyre and possible injury.
- Please note that for general use of the Pull-About, the front and rear walls must be connected.

Intended Use:

The Pull-About is not designed for transporting children, adults or pets.

Assembly Instructions — Adult assembly required.

The Pull-About


A smarter cart. Thoughtfully functional.

01.

Unpack your Pull-About

Remove Pull-About from the shipper and unpack the components. You should have the following:

1. 1 x Cart body
2. 2 x large Rear Wheels
3. 2 x Castors






02.

Open Side Walls

Open the Side Walls by grabbing the frames and pulling up and out. You will feel and hear them click into place when they are fully vertical.

See Storage for how to collapse walls



Assembly Instructions

03.


Unpack your Pull-About

Rotate the Pull Handle up and out.

Remove the large Rear Wheels from inside your Pull-About and put them aside. We'll fit them soon.

Remove the Castors from their cartons. Fit one at a time into their receptacles on the underside front frame of your Pull-About.

Be sure to push button B to lock the Castors in place as you insert.






04.

Fit Rear Wheels

Install the Rear Wheels one at a time by sliding each Wheel Axle inside it's frame receptacle.

Be sure to push button C to lock the Rear Wheels in place as you insert



Assembly Instructions


05.

Fit Front & Rear Walls

Ensure that the Pull Handle is still folded out into the forward position.

Lift the Front Wall Cross Bar up and insert its ends into the corresponding receptacles 'D' on the Side Walls, lowering from above. As you lower the Cross Bar down ensure the ends are correctly aligned with the sockets in the receptacles.

Repeat the process to fit the Rear Wall.






06.

The Pull-About

A smarter cart. Thoughtfully functional.

Ready to go

That's it, you're done! Your Pull-About is now fully assembled and ready for use.



Important: Before each use, ensure wheels are properly attached and your load is secured.

Product Care & Maintenance Instructions

We recommend washing off sand and salt water after coastal adventures.

For cleaning of the canvas, do not use bleach. Hand wash or wipe down with warm water and mild soap or detergent, then wipe dry.


Please check rear tyre pressure regularly and adjust as required to 36 PSI.

Storage

For longer product life, store out of direct sunlight in a dry, well-ventilated area and remove sand, dirt, or salt water.

Collapsing for Storage

When collapsing Pull-About for storage, simultaneously slide up the 2 collars E on the side wall to release lock and then fold side wall down. Repeat for other side.





Technical Specifications

Pull-About

Volume (top of side arms):	101 Litres
Net weight (cart only):	12.5kg
Gross weight (cart & packaging):	16.2kg
Frame Material:	Corrosive treated; powder coated steel
Base Material:	Injected molded plastic
Exposed screws/bolts:	Black nickel coated stainless steel

Rear Wheel


Type:	Inflatable tyre
Materials:	Aluminum and stainless steel
Air Pressure:	36 PSI

Castor Wheel


Type:	PU tyre
-------	---------

Size (MM)

Top View



Side View



Warranty & Repairs

Easterly has great confidence in the quality of our products. Subject to you using the product in accordance with our instructions, we warrant your new product to be free from defects in materials and workmanship for 12 months from date of purchase.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

While we can't replace damage caused by wear and tear or misuse, we may be able to provide repairs at a reasonable fee.

Additionally, its important to note that our manufacturer's warranty excludes damage arising from corrosion, a natural process in aging of steel or iron-based materials. Corrosion is not considered a defect and is therefore outside the scope of our warranty coverage.

For the comprehensive terms and conditions outlined in our full warranty document, please refer to our website at **easterly.au**



Thank you for joining Easterly.



Time better spent.

easterly.au